


FISKARS


4-in-1 embossing corner punch



How to use

Start with your punch on a craft mat to make sure you don't scratch your table. Slide the corner into the punch until it's flush to the back (flip it over to make sure it's lined up) and punch.

Don't let up or move your paper! Give it an extra push or two down for a crisp embossed design. This extra little push is the key, trust us.



www.fiskars.com

This punch can be used on heavy card stock, but we recommend 65 lb. card stock to get the best results.