

Instructions: Eyelet Setter

FISKARS®

How to Use Eyelet Setter:



1. To punch hole - Place the hole punch (purple end) on the paper. Always use a craft mat to prevent damage to surface underneath. Firmly grasp the purple grip with one hand, pull the grey grip straight up and release.
To prevent confetti jam in barrel: Use a paper clip to remove paper after every few punches.
For Best Results: Always pull spring straight up, not to the side or at an angle. Do not overstretch spring--- pulling spring beyond 2" may affect performance of product.
2. Place your eyelet in the hole. The front of the eyelet should be face down on the craft mat.
3. To set the eyelet - Place the setting tip (grey end) in the eyelet. Firmly grasp the grey grip with one hand, pull the purple grip straight up and release. Repeat as necessary.