


Fiskars® Softgrip Craft Knife

- Ergonomic handle for easy control
- All over Softgrip for comfort
- Strong protective sheath
- Uses standard blades
- Maximum thickness : **250gr, recommended 210g**




1. Softgrip Craft Knife features



2. How to use the Softgrip Art Knife:

For best results when cutting, you must ensure that the Softgrip Craft Knife has been adjusted to suit the type and depth of paper being used. Adjust the depth of the blade by your hand pressure.

Right cutting



When using the Softgrip Craft Knife it is best to use a mat to protect your work surface.

The Fiskars® transparent cutting mat (ref 8610 or 8608) allows you to protect your work surface and prolongs the use of your cutting tools.

One side has a self-healing surface for cutting and the other side is useful for all your painting, collages, felt pens and other projects.

The main feature of this mat is its flexibility, it helps to deliver a smoother cut when using the Softgrip Craft Knife.



FISKARS®

3. Changing the cutting blade

When changing the cutting blade, you must tighten the metal part to allow the blade to get it out.

To protect extra blades of the Softgrip Craft knife, you can store them in the transparent compartment.



For security reasons, never leave your Softgrip Craft Knife upright without its orange cover as this may damage the blade.